



HOW TO USE YOUR FREEPLAY ENCORE WIND-UP AND SOLAR POWERED RADIO AND MP3 PLAYER

If Player runs out of power while you are listening to it, first switch it off before you recharge it with the wind-up handle or the solar panel.



How to Use the Fixed Solar Panel and the Accessory Solar Panel (if supplied)

Fixed Panel.



Place the radio in the sun so that the sunlight falls onto the solar panel on the top/back of the radio.

Accessory Panel. The solar panel will only work if it is plugged into the hole on the side of the Player. The solar panel needs to be placed in direct sunlight to give the Player power.

